




(-41C)

## Syncro Torsion Knee - Tilt Control with Ergo Tilt Seat and Seat Slider



VIA Customer Service: 800-433-6614

- 1 Seat Height Adjustment** - Adjust the seat height by lifting the paddle (located just below front, right corner of the seat cushion). Proper seat height is realized when the top of your legs are somewhat parallel to the floor.
- 2 Body Weight Adjustment** - Adjust the body weight tension knob (located just below front, right corner of the seat cushion) to your personal body weight. Rotate knob toward the center of the chair to increase the tilt tension. Rotate away from the center of the chair to loosen the tilt tension.
- 3 Tilt Lock Adjustment** - To unlock the tilt control simply rotate the adjustment knob toward the rear of the chair (located on the left side, center - just below the seat cushion). To lock the tilt angle, rotate the adjustment knob toward the front of the chair.
- 4 Sliding Seat Adjustment (Standard)** - Pull lever up to adjust seat slide forward or back. Push down to lock seat slider in position.