



5C-Control Advanced Task Control



- ❶ **Seat Height** - Adjusts from 16.5" to 21" H. To raise height, lift weight off seat and pull lever upward. To lower seat, while seated, pull lever upward.
- ❷ **Back Angle** - Adjusts from four degrees forward to eighteen degrees back. Pull lever upward and shift your weight forward or back to desired angle. Release lever to lock. To free float the back, pull lever upward until locked.
- ❸ **Body Weight** - Rotate knob to the left to increase tension. Rotate knob to the right to decrease tension.
- ❹ **Seat Angle** - Adjusts from six degrees forward to 3 degrees back. Pull lever upward to lock. Shift your weight forward or backward to desired seat angle. Release lever to lock. To free float the seat, pull lever upward until locked.
- ❺ **Slide Seat** - (if ordered) Adds 2.5" to seat depth. Pull lever upward and hold, slide seat forward or backward by shifting your weight. Release lever.
- ❻ **Arm Rest Height** - (if ordered) Adds 2.5" to the arm height. (Trigger controls, under each arm pad). Depress trigger with finger tips and lift or lower arm pad to desired height. Release trigger.
- ❼ **Back Lumbar Adjustment** - To adjust lumbar, lift backrest cushion to its top position, then push cushion down to its lowest position, raise to desired height.

5C-Control Advanced Task Control



- ❶ **Seat Height** - Adjusts from 16.5" to 21" H. To raise height, lift weight off seat and pull lever upward. To lower seat, while seated, pull lever upward.
- ❷ **Back Angle** - Adjusts from four degrees forward to eighteen degrees back. Pull lever upward and shift your weight forward or back to desired angle. Release lever to lock. To free float the back, pull lever upward until locked.
- ❸ **Body Weight** - Rotate knob to the left to increase tension. Rotate knob to the right to decrease tension.
- ❹ **Seat Angle** - Adjusts from six degrees forward to 3 degrees back. Pull lever upward to lock. Shift your weight forward or backward to desired seat angle. Release lever to lock. To free float the seat, pull lever upward until locked.
- ❺ **Slide Seat** - (if ordered) Adds 2.5" to seat depth. Pull lever upward and hold, slide seat forward or backward by shifting your weight. Release lever.
- ❻ **Arm Rest Height** - (if ordered) Adds 2.5" to the arm height. (Trigger controls, under each arm pad). Depress trigger with finger tips and lift or lower arm pad to desired height. Release trigger.
- ❼ **Back Lumbar Adjustment** - To adjust lumbar, lift backrest cushion to its top position, then push cushion down to its lowest position, raise to desired height.